

The home of the turntable

THE VINYL ENGINE®

For more turntable manuals and setup information
please visit www.vinylengine.com

Service Manual

Technics
by Panasonic

STEREO
Technics
by Panasonic

Supplementary-1

MODEL SL-1300

- * This service manual includes only the changes of the SL-1300 service manual (ORDER NO. SD7407-418).
- * This manual should be filed with the service manual for model SL-1300 (ORDER NO. SD7407-418)

CHANGES

● Addition

○ Deletion

■ REPLACEMENT PARTS LIST

Ref. No.	Change of Part No.		Description	Per Set (Pcs.)	Remarks
	Old Part No.	New Part No.			
2	SFTG120-01	SFTG130-01	Turntable sheet	1	
3-2	XYN4+C8FUS	XYN4+C10FUS	Screw for stater frame	3	
5-2	XYN3+C10FUS	XYN3+C12FZS	Screw for hinge assembly	4	
7-2	SFUM130-02	XUC4FY	E-shaped ring	1	
10-2	XYN3+6FUS	XYN3+8FUS	Screw for switch plate	2	
12	AM9715	AM7620-44	Micro Switch	1	
13-2	XYN3+C6FUS	XYN3+C8FUS	Screw for mounting plate	1	
14	EVHBOAK15B52	EVHBOAK15B62	Variable resistor	2	
16-6	XYN3+C6FUS	XYN3+C8FUS	Screw for terminal strip ass'y	2	
17-2	XYN3+C6FUS	XYN3+C8FUS	Screw for fixing plate	2	
21-2	XYN4+8FUS	XYN4+C8FUS	Screw for transformer	2	
23	SFEB6BT130	SFEB6UT130	Vinyl tube for transformer and mechanism block	2	
25-2	XSN3+6FUS	XSN3+C6FUS	Screw for circuit plate ass'y	4	
25-3	XYN3+C6FUS	○	Screw for circuit plate ass'y	0	
29-2	XYN3+C6FUS	XSN3+5FUS	Screw for neon lamp	3	
37	EPA-13C	EPA-130A	Tonearm assembly	1	
37-2	XYN3+C10FUS	XYN3+12FUS	Screw for tonearm assembly	3	
38-2	XYN3+C6FUS	XYN3+C8FUS	Screw for automatic mechanism assembly	6	
41-2-1	●	SFXW022-1	Washer for audio insulator	4	
41-5	XSN3+10FV	XSN3+C10FZS	Screw for bottom cover	5	
41-6	XSN3+35FV	XSN3+C33FZS	Screw for bottom cover	7	
41-7	XWA3BF	○	Spring washer for bottom cover	0	

Ref. No.	Change of Part No.		Description	Per Set (Pcs.)	Remarks
	Old Part No.	→ New Part No.			
51-2	XSN3+10FU	XYN3+C12FUS	Screw for arm base	2	
51-3	XWA3BFU	○	Spring washer for arm base	0	
53	SFP-WG13002	SFP-WG11002	Auxiliary weight	1	
55	SFP-JK13001	SFP-JK13001K	Anti-skating force control knob assembly	1	
57-2	SFXW551D2	SFXW702-2	Washer for canceler cam B	1	
57-3	XUC3FY	○	E-shaped ring for canceler cam B	0	
60	SFP-RT13001	SFP-RT13001K	Arm rest assembly	1	
61	SFP-JK13007K	SFP-JL13007K	Cueing lever assembly	1	
65	SFP-RT13003	SFP-RT13003K	Arm lift assembly	1	
66-2	XSN3+4FU	XYN3+5FUS	Screw for arm lift base	3	
66-3	XWA3BFU	○	Spring washer for arm life base	0	
71-4	XUC5FU	XUC5FY	E-shaped ring for operating plate assembly	1	
72-3	XUC5FU	XUC5FY	E-shaped for main gear	1	
73-2	XUC3FU	XUC3FY	E-shaped ring for gear set plate	1	
79-3	XUC3FU	XUC3FY	E-shaped ring for repeat cam	1	
80-3	XUC3FU	XUC3FY	E-shaped ring for select cam	1	
81-3	XUC3FU	XUC3FY	E-shaped ring for start cam	1	
85-2	SFXW890B01	SFXW130-12	Washer for cut plate	1	
85-3	XUC5FU	XUC5FY	E-shaped ring	1	
88-2	SFXW890B01	SFXW130-12	Washer for select lever	1	
88-3	XUC5FU	XUC5FY	E-shaped ring for select lever	1	
89-2	XUC3FU	XUC3FY	E-shaped ring	1	
90-2	XUC3FU	XUC3FY	E-shaped ring for supporting plate	1	
92-2	XUC3FU	XUC3FY	E-shaped ring for actuating plate	1	